



Landscape Posts & Chain Accessory Pack for Double Chain

5200-2CBSS

Installation Instructions

Before you begin installation, please consult your local building code and/or pool code to ensure this product is suitable for your application. Periodic maintenance and testing to ensure proper operation is recommended.



Package Contents:

- 2 Black Link to Screw
- 2 Black Hex Bolts
- 2 Black Washer
- 2 Black Nuts

Recommended Tools:

- Power drill with a bit suitable for metal
- Measure Tape
- Marking tool
- Bolt Cutters for chain
- 10mm Socket
- 10mm Wrench



Measure distance



Install posts



End Post Install



Line post



Row of Posts

Prior to in ground installation:

Determine the height at which the second row of chain will be hung. Measure down the post and place the quick link, mark the holes to be drilled. Drill your holes. Premeasure for each post using the same procedure. Once all the posts have been drilled, you can continue with installing the posts into the ground.

To begin installation

With the top line of chain installed. Align your chain to the same swag (droop) as the top line of chain. Pre-cut your chain to the required lengths, allowing for the appropriate amount of swag, as you go.

End Post Installation

Slip the link to screw through the last link of the chain, insert the two hex head bolts from the opposite side through the link to screw and into the post at the pre drilled holes. Affix the washer and nut to the chain side of the post. This will create a finished look from the outside of the post.

Line Post Installation

Slip the link to screw through the last link of the chain, insert the two hex head screws through the link to screw and into the post at the pre drilled holes. Slip the link to screw through the second piece of chain and attach this link to screw to the site where the bolts are showing through. Affix the washer and nut to the exposed bolts.