

HARDWARE MAINTENANCE

Borg Locks

Keep your lock looking great and functioning well with a few basic steps:

1. Carefully remove your Borg Lock from the gate or door to allow lubrication access to the back.
2. Use warm, slightly soapy water along with a clean sponge and/or a soft bristled brush to gently clean away any dirt or foreign substances settled on the face surface of the lock. We recommend the Dawn basic formula dish soap.
3. Rinse thoroughly with fresh warm water to remove all the soap.
4. Dry and buff with a clean cotton cloth.
5. Lubricate the mechanical parts (from the front and back) of the lock using a clear silicone-based spray lubricant. Do not use an oil-based spray like WD-40 as it will attract dirt and debris.
6. Push each of the buttons and rotate the knob to allow for lubricant penetration while ensuring your desired operation is achieved.
7. Wipe off any excess spray and buff the lock with a clean, dry cloth.



WHEN?

Follow the above procedure any time the lock looks like it needs a clean or if the lock operation becomes "sticky" or code entry becomes intermittent, typically 1-2 times per year.